

DR-RWM-AD

TruVision Adapter for TruVision Dome

Overview

DR-RWM-AD TruVision Adapter for the TruVision Dome to use on the DR wall-mount and TVD-M2-WM wall-mount bracket

DR-RWM-AD used on DR-RWM wall-mount bracket:

Use hole 1 for the following cameras:

TruVision IP wedge cameras with adapter:

PAL: TVD-N210W-4-P, TVD-M1210W-2-P,
TVDM1210W-2W-P, TVD-M2210W-4-P, TVW-1101, TVW-1102
NTSC: TVD-N210W-4-N, TVD-M1210W-2-N,
TVDM1210W-2W-N, TVD-M2210W-4-N, TVW-3101, TVW-3102

TruVision wireless IP wedge cameras with adapter:

PAL: TVW-1103, TVW-1104, TVW-1105, TVW-1106
NTSC: TVW-3103, TVW-3104, TVW-3105, TVW-3106

TruVision analog wedge cameras with adapter:

PAL: TVW-2101
NTSC: TVW-4101

DR-RWM-AD used on TVD-M2-WM wall-mount bracket:

Use hole 2 for the following cameras:

TruVision IP plastic dome

PAL: TVD-1105, TVD-1106,
NTSC: TVD-3105, TVD-3106

TruVision IP indoor plastic dome

PAL: TVD-1101, TVD-1102,
NTSC: TVD-3101, TVD-3102

TruVision HD-TVI plastic dome

PAL: TVD-2401, TVD-2403
NTSC: TVD-4401, TVD-4403



Standard Features

- Suitable for the TruVision Dome
- TruVision Adapter
- Aluminum alloy

DR-RWM-AD

TruVision Adapter for TruVision Dome

Ordering Information

Part No.	Description
DR-RWM-AD	TruVision Adapter for TruVision Dome

