

Wireless Door/Window Contact

DWC-102

User Manual




Introduction

The DWC-102 is a Door/Window Contact that can be installed on doors, windows, and any other objects that open and close.

The sensor transmits signals to the control panel when a magnet mounted near the sensor is moved away. It will also transmit alert signal to the control panel in case of low battery.

External input for wired accessory is available at the N/C interface. The tamper protection ensures that sabotage attempts to move the contact will result in an alarm activation.


Product Overview



Specifications

Power supply		DC 1.5V (AA 1.5V LR6 Battery x 1 pc)			
Static current	≤ 35	uA	Alarm current		≤ 10mA
Transmitting distance			≤80m (in open area)		
Radio frequency		315MHz/433.92MHz (±75KHz)			
Housing material ABS p			lastic		
Operating temperature			-10°C~+55°C		
Relative humidity			≤80% (non-condensing)		
Transmitter dimensions (LxWxH)				71 x 34 x 17.5mm	
Magnet dimensions (LxWxH)				51 x 12 x 13.5mm	

PCB Layout



NOTE: Tamper will be triggered no matter the door/window contact is armed or disarmed.

LED Indication

LED flashes once: Door/window is opened and transmitter sends signal to the control panel.

Flash once per 3 seconds: Low power indication, please change battery as soon as possible. (User will get alert SMS about the low battery if the door contact is connected to the GSM alarm system.)

Installation & Notice

- · Open the case and remove the battery activation strip.
- · Mount the sensor on the door frame and the magnet on the door.
- Make sure the magnet is on the right side of the transmitter
- Place the transmitter in the desired location, mount the magnet no more than 1cm away from the transmitter and secure the transmitter and magnet with double-sided tapes or screws.
- Avoid mounting sensors in areas with a large quantity of metal or electrical wiring, such as a furnace or utility room.

